



Thank you for selecting SureRock® products. Attached are SureRock's recommended installation instructions for Exterior Fiberglass Pre-Hung Doors. Read these instructions thoroughly before beginning. They are designed to work in most existing applications; however, existing conditions may require changes to these instructions. If changes are needed, they are made at the installer's risk. For installations other than Indicated in these instructions, contact a building professional.

1 CHECK YOUR ROUGH OPENING FIRST

- The rough opening (RO) is ideally 1" wider and ½" taller than the outside frame dimensions of the door unit you are going to install.
- The RO is Clean, Dry and Level.
- The old door frame has been completely removed in retro fit installation.

2 CAULK THE SUB FLOOR

- Caulk is applied in three parallel lines running the width of the sill.
- Apply three 1/3" lines of caulk along the length of the sub-floor, the first line starting approximately 1" from the inside edge. The lines should be about 1" apart.

3 GET THE NEW DOOR READY

- Remove any pre-hanging clips that are fastened to the outside of the jamb that will be covered when the unit is placed in the rough opening. Adequately support the slab to keep it from swinging open during installation.

4 PLACE DOOR IN ROUGH OPENING

- Place the sill in the opening first and then tilt the door up into the opening

5**INSTALL DOOR**

- Single Door: Keep the door centered and the frame tight against the sill. Shim the top of the door on the latch side. Install shims until there is a consistent 1/8" gap between the top of the door slab and the frame header.
- Double Door or Door with Side Lite: If installing a door with a sidelight(s), shim the head on both sides of the joint where the sidelight joins the door jamb. Fasten next to the shims and then remove shims. Shim the head of double door units or units with sidelight(s) at the center of each slab/sidelight. Fasten next to the shim and then remove shims. Fasten a transom in a similar manner every 16". From the inside of doors with sidelights installed on a wood floor, pre-drilled screws and fill the holes with sealant. Some double door units may require installing lock bolts at the top and bottom of the inactive panel. Follow the instructions that come with the product if available. Otherwise, locate the center point of each lock bolt, drill 3/8" bolt holes and install keeper plates.

6**FINISH INSTALLATION**

- Re-check for smooth door operation and even spacing between the door and door jamb.

Please visit surerock.us/resources for finishing instructions, warranty and care and maintenance information.

Thank you for choosing

